MEIKO MIDDLE EAST FZE Emaar Gold & Diamond Park, Building 6, Office 207 Sheikh Sayed Road P. O. Box 282365 Dubai UAE Tel: +971-341-5172 / Fax: +971-4-3415173 www.meiko.ae

M-iClean UM – Undercounter dishwasher

All MEIKO dishwashing machines are designed and built to provide maximum efficiency. That's what customers expect – and that's exactly what they get. But the M-iClean goes even further. Equipped with the full spectrum of innovative warewashing technology, the M-iClean's intuitive operating concept ensures maximum efficiency and reliability.

Execution for: Saudi Arabia

Dishwashing machine Fresh water line: Soft cold water 0-3 °dH 3-phase current: 3N PE 400V 60Hz GiO MODULE (separate) Thermolabel





Gio Module (separately) Dimensions: 600 x 700 x 600 mm

Technical data

Rack capacity/h (theoretical) Programme cycle Rack dimension Entry height Dimensions (W x Hmin x D)

Electrical feeding cable

Local fuse protection Machine protection class

Equipment

Fresh water line

Fresh water supply

Flow rate

40 / 30 / 20 racks/h 90 / 120 / 180 s 500 x 500 mm 315 mm 600 x 700 x 600 mm

Concentrate 3.4 l/min

3-phase current 3N PE 400V 60Hz* Total connected load: 11.4 kW max. rated current: 19.6 A

25 A IP X5

Control system MIKE CPU4 Bluetooth interface for wireless communication Leakage detector Boiler safety device Automatic self-cleaning when tank is drained Thermolabel Integrated reverse osmosis (including 10 µm filter with activated carbon) Chlorine-resistant membrane (> 0,1 mg/l bis 2,0 mg/l) Internal: air gap 'AB' in accordance with EN 1717 with booster pump Minimum flow pressure 100 kPa / 1.0 bar in front of solenoid valve Maximum pressure 500 kPa / 5.0 bar in front of pressure reducer Max. supply water temperature 35 °C total 5.4 l/min (at 15 °C inlet temperature) Permeate 2.0 l/min

1



Fresh water thresholds	Temperature cold water min. 1 °C to max. 35 °C electrical conductibility 70 - 1000 μ S/cm Total hardness max. 28 dH / 5 mmol/l CaCO3 Free of particles > 10 μ m Iron < 0.10 mg/l Manganese < 0.04 mg/l Chlorine > 0.10 mg/l (free chlorine) Potassium permanganate < 10 mg/l Silicic acid < 10 mg/l
Final rinse water quantity	2.4 liters/cycle, variable
Boiler	Contents: 7.9 I Heater: 6.00 kW Temperature: 83 °C
Wash tank	Filling: 11.0 l Heater: 4.50 kW Temperature: 74 °C
Wash pump, with frequency converter	Performance: 0.50 kW
Dosing of rinse aid	Hose pump (24 V) with time control and suction lance
Detergent dosage	Hose pump (24 V) with time control and suction lance
Material	Cladding: 1.4301 Wash tank: 1.4301 Boiler: 1.4571
Heat emission	for 10 programme cycles/h total: 1.1 kW perceptible: 0.7 kW latent: 0.4 kW
Ventilation flow rate	270 m³/h
Steam emission	0.5 kg/h
Emission sound pressure level at the workplace (LpA)	60 dB
Net / gross weight	86.8 kg / 98.6 kg (standard packaging)
Packaging dimensions (W x H x D)	700 x 1050 x 700 mm (standard packaging)

*Note:

Electrical equipment suitable for supply voltage: 3N PE 400 V 60 HZ (3N PE 380-415 V 60 Hz) 1N PE 230 V 60 HZ (1N PE 220-240 V 60 Hz)

1.0	machine connection: drain connection hose, DN 22 hose fitted as odour trap in interior of machine	
1.1	drain (max. 420 mm above finished floor level), DN 50	GIO MODULE (W x D x H) 140 x 560 x 600 mm Connecting pipe from the module to the machine, 3 m long
2.0	Machine connection: fresh water supply, G 3/4"	
2.2	Soft cold water 10°C, DN 15, G 3/4 a max. 0,54 mmol/I CaCO ₂ (max. 3°dH) Flow rate: min. 8 I/min electrical conductibility 70 - 1000 µS/cm Minimum flow pressure: 100 kPa / 1.0 bar in front of solenoid valve Maximum pressure: 500 kPa / 5.0 bar in front of pressure reducer stopcock and fine screen ≤ 25 µm	300 315 275 315 275 315 275 55 545 710-735 710-735 710-735
3.0	Machine connection: electrical connection cable 5G 4mm ²	
3.1	electricity supply to the machine: 3N PE 400V ~ 60Hz nominal current / - capacity: 19.6 A / 11.4 kW Fuse protection: 25 A () Voltage equalising cable The master switch must be provided on site	
	Note: Electrical equipment suitable for supply voltage: 3N PE 380-415 V 60 Hz / 1N PE 220-240 V 60 Hz	
6.0	Heat load of warewash area	
6.1	for 10 programme cycles/h total 1.1 kW, perceptible 0.7 kW, latent 0.4 kW	2.2
all ca	oles, pipes etc leaving machine 1,6 m	
the p	sition of the connection piping can also be mirror-inverted!	
Mad	hine Equipment	
	try height	
Final	inse dosing unit with suction lance (blue connector)	
	gent dosing unit and suction lance	
	IODULE (separate) M2	
	ne-resistant membrane (> 0,1 mg/l bis 2,0 mg/l)	Ф
	nolabel	
A	Please observe the installation indications of the additional	
∕!∖	document MP_T-INFO-GIO_M2_M-iClean-U_EN.pdf	Revision
	·	MEIKO MIDDLE EAST FZE GoldDiamond Park, Building#6, office #206 P.O. Box 282365, U.A.EDubai Phone +971 43 41 51 72 E-MAIL: wat@meiko.de
MP000406116.2.2	This drawing may not be neither passed to third parties for their information or copied or used for competitive purposes without our consent. All rights reserved. We reserve the right to make changes resulting from technical progress. This drawing was computer generated and provide. No.	
	make changes resulting from technical progress. This drawing was computer generated and is not subject to the checking and any release process; it is also not subject to change management. Please note: Order-No. S00079464	
	This document is only valid in conjunction with the conditions defined in Supplementary Sheet "Important Information". These can be requested from the manufacturer or downloaded from the Partment. Scale drawn: 23.04.2020 m-iplan 23.04.2020 m-iplan	
	RIGHT by MEIKO	SAU EN ©COPYRIGHT by N

3